



Art: 72124
GU10 LED Max. 5W
230V~50Hz

The diagram illustrates the assembly of a four-light pendant fixture. The main view shows the fixture with four cylindrical shades hanging from a horizontal bar. A screwdriver is shown adjusting the height of the shades. A detailed inset shows the wiring connections for the four lights, labeled 1 through 5, and a legend for the wiring symbols.

Wiring Legend:

- L**: Line (solid black line)
- N**: Neutral (dashed line)
- ⊕**: Ground (line with a cross)
- ⊖**: Ground (line with a cross)

Assembly Steps:

1. Connect the Line (L) wire to the terminal marked 'L'.
2. Connect the Neutral (N) wire to the terminal marked 'N'.
3. Connect the Ground (⊕) wire to the terminal marked '⊕'.
4. Connect the Ground (⊖) wire to the terminal marked '⊖'.
5. Adjust the height of the shades using the screwdriver.

A diagram of a 16-pin DIP package. A finger is shown pressing one of the internal switches to the 'ON' position, indicated by an arrow and the text 'ON'.