




902386/902387/902388/902389
902391/902392/902393/902394



www.eglo.com

The screw connection for the sensor must remain closed when NOT IN USE

